

Zoomer dropout extension kit for 26" rear wheel

10/30/09

Parts list:

- 1 left dropout
- 1 right dropout
- 1 rear wheel (26", 32h silver rim, black hub, SS spokes, brass nipples)
- 1 tire (CST for Zoomer standard, Schwalbe Marathon for Zoomer Elite)
- 1 tube (26x1.75)
- 1 rim strip
- 4" of 9 speed chain (Zoomer Elite w/ quick link)
- 4" of 8 speed chain (Zoomer Standard w/ quick link)
- 2 M6x12mm BHSCS SS
- 2 M6 washers
- 2 M5x12mm SHCS SS
- 2 M5 flat washers

Instructions:

To install the dropouts simply:

- 1) Remove the 20" wheel
- 2) Remove derailleur
- 3) Remove the silver derailleur hanger
- 4) Install dropout extensions into existing dropouts making sure that the extension w/ the derailleur hanger is on the right side of the trike.
- 5) Place washers over the bolts and thread them into the drop outs.
- 6) Add the proper amount of chain to compensate for the extension of the drop outs (if the boom length hasn't been changed, the 4" of chain provided should be enough).
- 7) Swap the cassette from the 20" wheel to the 26" wheel. If you don't have the proper tools for this operation, contact your local bike shop for assistance.
- 8) Reattach the derailleur to the new derailleur hanger.
- 9) Insert the wheel into the dropouts, put air in the tires, and you're ready to ride!

Bolt Torque Specs:

M5 w/lube = 25 in-lbs.
M5 w/o lube = 50 in-lbs.

M6 w/lube = 40 in-lbs.
M6 w/o lube = 80 in-lbs.

