

Tools Needed: 5mm Allen Wrench

Assembly Instructions:

Using a 5mm Allen Wrench, remove the stock steering Top Cap and bolt. Install the Accessory Top Cap Mount using the stock bolt. Steering adjustments may be required after installation. Refer to the TerraTrike Quick Start Guide for proper steering adjustment (<https://www.terratrike.com/resources/manuals/>).

